


TIZEN Installation Guide

UCView Digital Signage TIZEN Installation on Samsung SMART Screen

1. Connect your Samsung TV to the WiFi network.



- 2. Press the menu button on your TV controller.
- 3. Scroll down to Network.



4. Select your Network type. In this case, select **Wireless**.



5. Select your desired wireless connection.




- 6. Enter your wireless password.
- 7. Once you are successfully connected to the wireless network, press **OK**.




8. In the Menu, scroll down to System.




9. Scroll to Play via and then select the URL Launcher option.



10. Once prompted with the URL Launcher settings, please enter the **UCView URL**: http://portal.ucview.com/player/tizen and then select **Done**.




- 11. Press the Home button on your TV controller.
- 12. Once you see the **Home** menu select the **URL Launcher**.



13. Installation of the UCView web app will automatically begin.

14. Finally you will be shown the player password that you can use to enter in the UCView web portal to register the player.



15. Select the **Your Digital Signage Portal Account** hyperlink to login to UCView's web-based interface.

